

USER GUIDE

kogan.com



1000W ROCKET BLENDER PRO SET

(8-PIECE)

KANMB8PC1WA

SAFETY & WARNINGS

ATTENTION! Please handle this product with care and inspect it regularly to ensure it is in good working order.


If the product, power supply cord or plug shows any signs of damage: stop use, unplug and contact Kogan.com support.

Before using the appliance, read the below instructions in order to avoid injury or damage and to get the best results from the appliance. There is a potential risk of injuries from misuse.

- Always disconnect the appliance from the power supply if it is left unattended or before assembling, disassembling or cleaning.
- This appliance shall not be used by children. Keep the appliance and its power cord out of reach of children.
- The appliance can be used by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and if they understand the hazards involved.
- If the power supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- Switch off the appliance and disconnect from the power supply before changing accessories or parts that move when in use.
- Care shall be taken when handling the sharp cutting blades, emptying the bowl and during cleaning to avoid personal injury.
- Before inserting the power plug into the mains socket, please check that the voltage and frequency comply with the specifications on the rating label.
- If an extension cord is used it must be suited to the power consumption of the appliance, otherwise overheating of the extension cord and/or plug may occur and this may lead to a fire.
- Ensure that the mains cable does not hang over sharp edges and is kept away from hot objects and open flames.
- Do not immerse the appliance or the mains plug in water or other liquids. There is a risk of electric shock.
- To remove the power plug from the mains socket, pull the plug. Do not pull the cord.
- Do not touch the appliance if it falls into water. Instead, remove the plug from its socket.
- Do not plug or unplug the appliance from the electrical outlet with a wet hand.
- Never attempt to open the housing of the appliance or to repair the appliance yourself. This could cause an electric shock.

- Children are unable to recognize the hazards associated with incorrect handling of electrical appliances. Therefore, children should never use electric household appliances unsupervised.
- Never leave the appliance unattended during use.
- This appliance is only designed for domestic use.
- Do not use the appliance for anything other than its intended use.
- Do not wind the power cord around the appliance and do not bend the power cord.
- The use of accessory attachments not recommended by Kogan.com may cause injuries.
- The blade is sharp. Please be careful when you wash it.
- Assemble the blade base with the blending cup tightly, otherwise, it will leak.
- Never put the blade on the motor base directly when use.
- Never put hot ingredients (above 65°C) into the cups.
- Please remove all hard kernels and seeds from fruit before blending.
- There is an overheat protection system in the motor, it will activate if the motor overheats. You should turn off the power if this activates and wait for the machine to cool down completely.
- Be careful of pouring hot liquid into the blender as it can be ejected out of the appliance and cause burns.

OVERVIEW



1 Blending cup

2 Cross blade

3 Blade base

4 Motor base

5 Grinding cup

6 Flat blade

7 Blade base

8 Flip-top lid

9 Storage lid

10 Control panel

11 Feet


OPERATION

CAUTION: Make sure the motor base is unplugged from the power source before beginning.

1. Place the motor base on a firm, flat and level surface.
2. Fill the blending cup with your ingredients and connect the cross blade for blending. Alternatively, fill the grinding cup with your ingredients and connect the flat blade for grinding. Rotate the blade base on to the cup tightly in a clockwise direction. Do not exceed the "MAX" level on the cup.
3. Rotate the cup into the motor base in a clockwise direction. Make sure the cup is firmly locked.
4. Plug the appliance into power.
5. Press the "ON/OFF" button to turn on the unit. Press the "LOW-HIGH" button once and the appliance starts working at low speed. Press it again and the appliance will work at a high speed.

If the blender does not turn on at this stage, refer to the below note. If it is working correctly, continue to step 6.

NOTE: This product is equipped with a safety switch ("A" in the image below) on the motor base. If the blender is not assembled correctly, the safety switch will not be activated, and the machine will not work when switched on. If the blender is not turning on, ensure that the blade base is attached to the motor blender securely. Do not use any external tools to press the safety switch, as this may damage the blender.



6. If you want to use the pulse function during operation, press the "PULSE" button once to let the appliance stop first and then press "PULSE" button again to run the appliance at full speed for 2 seconds. Repeat if needed.
7. After use, press the "ON/OFF" button to turn off the appliance and then unplug it.

Important

1. For blending, please cut ingredients into pieces if they are solid. Assemble the blade base with the cup tightly, otherwise, it will leak.
2. After 50 seconds of continuous operation, the appliance will stop automatically. This is an overheat protection measure and it is required to stop for 5 minutes to prevent overheating. After 5 cycles, let the appliance cool down completely.
3. Please make sure not to put any hard objects in the blender as they could damage the blade or the cup. Please remove all hard kernels and seeds from the fruit before blending.
4. The maximum weight of ingredients in the cup shouldn't exceed 120g.
5. The pulse function can be used for ice crushing and for cleaning purposes. When crushing ice cubes, please remember to add some water into the cup.

CLEANING & CARE

1. Always unplug the appliance before cleaning.
2. Do not immerse the motor base in water or any other liquids. Clean it with a damp cloth and dry thoroughly.
3. Disassemble other parts of the appliance after each use and wash them in soapy water. Then rinse with clean water and dry thoroughly.
4. Only the motor base cannot be cleaned in a dishwasher. The other parts are dishwasher safe if the temperature is not above 60°C. You can also use the pulse function for quick cleaning if needed.
5. Do not use any parts in a microwave.

Note:

Before using your appliance for the first time, clean all the accessories (except for the motor base) in warm soapy water. Rinse and dry thoroughly.

Disposal



This marking indicates that this appliance should not be disposed with other house-hold wastes. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources.

SPECIFICATIONS

Voltage

220-240V ~ 50/60Hz

Power

1000W

RECIPES

Healthy Green Smoothie

Ingredients:

- 100g spinach
- 1 avocado
- 2 bananas
- 300ml yoghurt

Method:

1. Add all the ingredients to the tall mixing cup and twist on the extractor blade.
2. Lock cup onto the motor base and mix until smooth.

Hummus

Ingredients:

- 60ml chicken or vegetable stock
- 400ml canned chickpeas (drained)
- 3 cloves of garlic
- 2 tsp lemon juice
- 3 tsp tahini (sesame paste)

Method:

1. Add all the ingredients into the tall mixing cup.
2. Twist on the extractor blade and blend until smooth.
3. Add salt and pepper to taste.
4. Serve with warm pita bread.

Strawberry Daiquiri

Ingredients:

- Ice
- 100ml daiquiri mix
- 50ml light rum
- A handful of fresh or frozen strawberries

Method:

1. Fill the tall mixing cup with the ice and strawberries and twist on the extractor blade.
2. Pour in the liquid ingredients and blend until smooth.

Margarita

Ingredients:

- Ice
- 50ml tequila
- 20ml fresh lime juice
- 20ml triple sec or Cointreau
- 1 tsp sugar

Method:

1. Fill the tall mixing cup with the ice and sugar and twist on the extractor blade.
2. Pour in the liquid ingredients and blend until smooth.

Classic Milkshake

Ingredients:

- Splash of milk
- A few scoops of vanilla ice cream

Method:

1. Add all the ingredients into the tall mixing cup and twist on the extractor blade.
2. Blend until smooth.
3. Add more milk if you want the milkshake to be thinner.
4. To create different flavours, add different ingredients to the classic recipe, for example, chocolate syrup, blueberry, strawberry, banana, peanut butter into the appliance and blend until smooth.

Iced Mocha

Ingredients:

- 2 cups of coffee
- 2 to 3 tsp of chocolate syrup (or cocoa powder)
- 2 cups of milk
- 1 to 2 tsp sugar (optional)
- 1 1/2 cups of ice

Method:

1. Brew a pot of coffee.
2. Fill the tall mixing cup with ice. Add chocolate, milk, sugar then fill the top of the cup with coffee.
3. Twist on extractor blade and blend until smooth.
4. Pour into cups and serve.
5. If you want, add whipping cream to a small mixing cup and blend with the flat blade for 5 seconds. Add to the top of the coffee and serve.

Strawberry Banana Smoothie

Ingredients:

- A handful of fresh or frozen strawberries
- 1 banana
- 1 cup of ice
- Splash of orange juice

Method:

1. Add all the ingredients to the tall mixing cup and twist on the extractor blade.
2. Lock-on and mix until smooth.

Need more information?

We hope that this user guide has given you the assistance needed for a simple set-up. For the most up-to-date guide for your product, as well as any additional assistance you may require, head online to **help.kogan.com**

kogan